



How it works

As the level of the liquid rises in the chamber the integral float on the pump is activated, the pump starts and pumps the liquid out of the chamber until the pump float drops and the pump turns off.

The level of the liquid will again rise and the above sequence is repeated.


If the pump fails to pump, the liquid level will rise to activate the high level float and the high level alarm light will be illuminated.

For applications involving more than one dwelling we would recommend our dual raw sewage pump station.

Features & Benefits

- Pump chambers are manufactured from high quality Glass Reinforced Plastic and in accordance with our BS EN ISO9001:2000 quality management system.
- Single phase and three phase pumps available.
- High level alarm included.
- Pump stations are delivered complete with the pipework and valves pre-assembled in the tank, ready for immediate installation into the ground.
- Low maintenance costs, servicing once a year.
- Custom made units available upon request.
- Servicing, Installation and Commissioning service available by our highly trained engineers.

Dimensions (mm)



| STORAGE CAPACITY / P/E | | | | | | |
|---------------------------|------|------|------|------|------|------|
| (A) INLET | 500 | 1000 | 1500 | 500 | 1000 | 1500 |
| (B) BELOW INLET | 900 | 900 | 900 | 1400 | 1400 | 1400 |
| (C) HEIGHT | 1400 | 1900 | 2400 | 1900 | 2400 | 2900 |
| (D) DIAMETER | 600 | 600 | 600 | 1000 | 1000 | 1000 |
| (E) OUTLET | 350 | 350 | 350 | 350 | 350 | 350 |
| | | | | | | |

Allerton® reserves the right to alter the specifications and dimensions without notice.

FOR FURTHER INFORMATON CALL: 01529 305757
EMAIL: sales@allertonuk.com

1 YEAR WARRANTY ON ALL WORKING PARTS



